Attaching the safety screen to a Jetmaster Universal wood or gas fireplace.

Step 1

Lift the screen with both hands from the handles, and hook (the lug) on to the top left hand corner of the firebox behind the flange as shown.

Step 2

Angle the screen at app 45 degrees so it sits into place into the top right hand corner with the lugs hooking in behind the flange.

Step 3

Allow the screen to drop down gently into place, flush to the firebox.

Step 4

To remove the screen – reverse the above steps, and place into the optional screen stand.

Jetmaster

NSW: 02 9597 7222 • **VIC:** 03 9429 5573 • **QLD:** 07 3263 4955 • **WA:** (Fireplace Corner) 08 9228 2600 • **SA:** 08 8371 1222 • **ACT:** 02 6280 6021

Web: www.jetmaster.com.au